


2" MODULE NEW CONSTRUCTION PLATE INSTALLATION GUIDE - WARNING

**WARNING** – Read all product labels and instructions before installing fixture.

**WARNING** – Wear safety gloves and other appropriate safety equipment.

DOWNLIGHT COMPATIBILITY & 2" MODULE DRYWALL NEW CONSTRUCTION PLATE

2" MODULE New Construction Plate	Compatible Products
 <div>MM2NCPLATE</div>	<div>MINIFIT 2" MODULE</div> <div>MM2/9XX/FL/DIM120</div> <div>With Trim MM2T/RFT/XX/XX or MM2T/RDT/XX/XX</div>

2" MODULE NEW CONSTRUCTION PLATE DRYWALL INSTALLATION

1. Nail or screw the MM2NCPLATE to the ceiling's studs/joists. Note MM2NCPLATE allow a maximum spacing of 24". Use the spacing distance marks on the side of the plate to center the downlight as desired. (fig. 1)
2. Secure the MINIFIT 2" Module's driver in the ceiling following the 2" MODULE installation instructions.
3. Make electrical connection following the appropriate 2" MODULE installation instructions.
5. Once ceiling is installed follow the appropriate 2" MODULE installation instructions to complete the installation. (fig. 2, 3, 4 & 5)

