

#### **FEATURES**

- Suitable for use with select GREEN CREATIVE fixtures and lamps. See complete list in below "COMPATIBLE FIXTURE AND LAMP" table
- Cold rolled steel housing, powder-coated. 48-3/4" flex conduit provided for easy connection
- Includes test switch and cover plate (mounts to single gang junction box not supplied)
- Dual voltage 120/277 VAC 60Hz input
- Constant power output in emergency mode for a minimum of 90 minutes
- Unit can be remote mounted up to 32 ft. Additional cable and connections supplied by others
- Meets or exceeds all National Electrical Code and Life Safety Code Emergency Lighting Requirements
- Integral short circuit protection
- Recyclable long-life high-temperature Lithium-ion battery
- Low Voltage Disconnect (LVD)
- Rated for use in damp locations
- Driver ambient temperature: 50°F to 122°F (10°C to 50°C)
- 5 year limited warranty\*
- Title 20 compliant
- cULus listed to UL 924 / CSA22 No. 141









SPECIFICATIONS						
Product	98003					
Model	23EMDRIVER					
Input Voltage	120/277VAC, 60Hz					
Input Current	120mA Max					
Input Power	8W Max					
Output Power	23W Max					
Open Circuit Voltage	143~150VDC					
Charge Time	24 hours					
Emergency Run Time	90 minutes					
Ambient Temperature	50°F to 122°F (10°C to 50°C)					
Battery	Hi-temp rechargeable, Lithium-ion					
Approval	UL 924 Listed, cUL Listed to CSA C22 No. 141, CEC Compliant					

<sup>\*</sup>Please visit www.greencreative.com for Limited Warranty terms.




## DIMENSION & WEIGHT





Model	23EMDRIVER	
Length	10-7/16"	
Width	2-3/16"	
Height	2-1/4"	
Weight	2.8 lb.	





IXTURE AND LAMP EM DRIVER COMPATIBLE GUIDE						
FIXTURE						
	Commercial Downlighting					
	NYXNC4RD/S9CCT5S/DUALDIM/xx/xx					
	NYXNC6RD/S9CCT5S/DUALDIM/xx/xx					
	NYXNC4SQ/S9CCT5S/DUALDIM/xx/xx					
	NYXNC6SQ/S9CCT5S/DUALDIM/xx/xx					
NYX	NYXICAT4RD/S9CCT5S/DUALDIM/xx/xx					
INIA	NYXICAT4SQ/S9CCT5S/DUALDIM/xx/xx					
	NYXDM4RD/S9CCT5S/DUALDIM/xx/xx					
	NYXDM4SQ/S9CCT5S/DUALDIM/xx/xx					
	NYXDM6RD/S9CCT5S/DUALDIM/xx/xx					
	NYXDM6SQ/S9CCT5S/DUALDIM/xx/xx					
	SLFT4/9CCT5S/DUALDIM					
	SLFT6/9CCT5S/DUALDIM					
	SLFT8/9CCT5S/DUALDIM					
	SLFT4/80CCTS/DIM010UNV					
	SLFT4/80CCT2750/DIM010UNV					
	SLFT6/80CCTS/DIM010UNV					
SELECTFIT	SLFT6/80CCT2750/DIM010UNV					
	SLFT8/80CCTS/DIM010UNV					
	SLFT8/80CCT2750/DIM010UNV					
	SLFT4/80CCTS/DIM120V					
	SLFT6/80CCTS/DIM120V					
	SLFT8/80CCTS/DIM120V					
	INFTP4/8CCT3S/DIM010UNV					
	INFTP6/8CCT3S/DIMO10UNV					
	INFTP8/8CCT3S/DIMO10UNV					
	INFTP6/8CCT3S/DIM120V					
	INFTP8/8CCT3S/DIM120V					
	INFT4/8xx/DIM010UNV					
INNOFIT	INFT6/8xx/DIM010UNV					
	INFT8/8xx/DIM010UNV					
	INFT4/8xx/DIM120V					
	14CDLA4/8xx/277V					
	INFT6/8xx/DIM120V					
	21CDLA6/8xx/277V/R					
	INFT8/8xx/DIM120V					
	MFR4/9CCT5S/DUALDIM/EXT  MFR6/9CCT5S/DUALDIM/EXT					
	MFR6HO/9CCT5S/DUALDIM/EXT					
	MFR8/9CCT5S/DUALDIM/EXT					
MULTIFIT	MFR8HO/9CCT5S/DUALDIM/EXT					
	MGR4/9CCT5S/DUALDIM/EXT					
	MGR6/9CCT5S/DUALDIM/EXT					
	MCR4/9CCT5S/DUALDIM/EXT					
	MCR6/9CCT5S/DUALDIM/EXT					
	MCR6HO/9CCT5S/DUALDIM/EXT					
	Residential Downlighting					
	10NCDLR4DIM/9xx/277V/EXT					
	12NCDLR6DIM/9xx/277V/EXT					
THINFIT EXT	24.5NCDLR8DIM/9xx/277V/EXT					
	10NCDLR4DIM/9xx/EXT					
	12NCDLR6DIM/9xx/EXT					
	24.5NCDLR8DIM/9xx/EXT					



FIXTURE AND LAMP EM	DRIVER COMPATIBLE GLUDE					
FIXTURE AND LAMP EM DRIVER COMPATIBLE GUIDE  FIXTURE						
FIXTURE  Residential Downlighting						
	8.5DLNC4DIM/8xx					
THINFIT	11.6DLNC6DIM/8xx					
	GIMB1/9xx/FL/DIM120					
MINIFIT	GIMB2/9xx/FL/DIM120					
	MM2/9xx/FL/DIM120					
	10DL4DIM/9xx					
RDL	12DL6DIM/9xx					
NDL	18DL6DIM/9xx					
	11DL6DIM/8CCTD					
	Surface Mount Downlighting					
	3N1/5/90/CCTS/DIM120V					
	3N1/7/90/CCTS/DIM120V					
	3N1/9/90/CCTS/DIM120V					
3N1 Downlight	3N1/12/90/CCTS/DIM120V					
	3N1/5/90/CCTS/DIM010UNV					
	3N1/7/90/CCTS/DIM010UNV					
	3N1/9/90/CCTS/DIM010UNV					
	CLK6/9xx/DIM120V					
	CLK6HO/9xx/DIM120V					
	10SMPR5.5DIM/9xx					
CLICK ROUND	15SMPR7DIM/9xx/R					
	15SMPR7DIM/9xx/277V					
	20SMPR9DIM/9xx					
	20SMPR9DIM/9xx/277V					
	10SMPS5.5DIM/9xx					
	15SMPS7DIM/9xx/R					
CLICK SQUARE	15SMPS7DIM/9xx/277V					
	20SMPS9DIM/9xx					
	20SMPS9DIM/9xx/277V					
	LAMP					
T5 Bypass Lamps	9.5T5HE/2F/8xx/BYP					
15 Bypass Lamps	11.5T5HO/2F/8xx/BYP					
	8T8/2F/8xx/BYP/RC					
	12T8/3F/8xx/BYP/RC					
	12T8/3F/8xx/BYP/R					
	10.5T8/4F/8xx/BYP					
	13T8/4F/8xx/BYP/RC					
T8 Bypass Lamps	14.5T8/4F/8xx/BYP					
	16T8/4F/8xx/BYP/RC					
	20.5T8/4F/8xx/BYP/R					
	17T8U6/8xx/BYP/R					
<u> </u>	13T8/4F/DIM/8xx/BYP					
<u> </u>	13T8/4F/8xx/GL/BYP					
	12T8/3F/8xx/BYP/FF					
T8 Bypass Flicker Free Lamps	8T8/2F/8xx/BYP/FF					
то рураз Filcker Free Lamps	13T8/4F/8xx/BYP/FF					
CCT Select PinFit PL Omni Lamps	9PLO/8CCTS/HYB/PF					
PinFit PL Omni Lamps ——	6.8PLO/8xx/HYB/PF					
	9PLO/8xx/HYB/PF					
CCT Select PL Hybrid Lamps ——	8PLH/8CCTS/HYBM					
DI Dimono 9 I hitarial Dimono 1	8PLV/8CCTS/HYBM					
PL Bypass & Hybrid Bypass Lamps	8PLH/8xx/HYBM  - Tel / Fax: (866) 774-5433 - 🕈 / GREENCREATIVELED 😈 / GClightingLED 📆 / GREEN-CREATIVE					




FIXTURE AND LAMP EM DRIVER COMPATIBLE GUIDE						
LAMP						
PL Bypass & Hybrid Bypass Lamps	8.5PLV/8xx/HYBM					
	15.5PLH/8xx/BYP/R					
	16.5PLV/8xx/BYP					
	7PLO/8xx/HYBM					
	9PLO/8xx/HYBM					
PLL Bypass Lamps	8.5PLL/8xx/GL/BYP					
	10PLL/8xx/GL/BYP					
	16PLL/8xx/GL/BYP					
	17PLL/8xx/BYP/R					

xx -Refers to the CCT yy - Refers to model generations within the same nominal performance Typically blank, 'R', or 'RC'

#### INSTALLATION

- 1. Make sure the POWER IS TURNED OFF at the source to the location at which you are installing the unit.
- Secure the EMERGENCY DRIVER to the fixture or in a position in the ceiling that does not interfere with any existing hardware. Installation should comply with local and national electrical code.
- 3. For switched power applications, make sure an unswitched line also exists in the J-box or fixture wiring compartment.
- 4. The unit connector is not in this conduit. They would have to install the single gang box with test light and button before the can pair the unit connector.
- 5. For unswitched constant power applications (emergency only, light is off in normal condition) connect the incoming unswitched line to the unit's black/white switched line.
- 6. Install the test accessory plate in a single-gang switch box (provided by others) in the ceiling near the fixture and wire according to the wiring diagram below. Make sure the indicator light and test switch are wired correctly.
- 7. For testing and maintenance, refer to the Test Button & Indicator Light section below.
- 8. Restore power at the source and installation is complete.



ORDERING INFORMATION							
Model	Master Carton		Shipping Carton				
	Case Qty	Case Dimensions (LxWxH)	Case Weight	Case Qty	Case Dimensions (LxWxH)	Case Weight	
23EMDRIVER	N.A.	N.A.	N.A.	6PCS	19-1/16" x 17-1/16" x 11-9/16"	23.15lb	

Where xxx means 824-965 which indicates CRI and color temperature
Note: All rights reserved. All sizes and specifications are subject to change at any time without notice